

G25 Engine

Safety, Operation, Maintenance & Parts Manual

LT20 Series

rev. E2.03



Safety is our #1 concern! Read and understand all safety information and instructions before operating, setting up or maintaining this machine.

Form #825

Table of Contents

Section-Page

| | | |
|------------------|---|------------|
| SECTION 1 | OPERATION | 1-1 |
| 1.1 | Starting The Engine | 1-1 |
| SECTION 2 | MAINTENANCE | 2-1 |
| 2.1 | Safety | 2-1 |
| 2.2 | Engine Oil & Filter | 2-2 |
| 2.3 | Cooling System | 2-2 |
| 2.4 | Air Filter & Pre-Cleaner | 2-2 |
| 2.5 | Fuel Filter | 2-2 |
| 2.6 | Battery | 2-3 |
| 2.7 | Alternator Belt | 2-4 |
| 2.8 | RPM Adjustments | 2-5 |
| 2.9 | Drive Belt Adjustment | 2-6 |
| 2.10 | Clutch Handle Adjustment | 2-7 |
| 2.11 | Miscellaneous Maintenance | 2-8 |
| SECTION 3 | REPLACEMENT PARTS | 3-1 |
| 3.1 | Fuel Tank Assembly | 3-1 |
| 3.2 | Engine Mount Assembly | 3-2 |
| 3.3 | G25 Engine Assembly | 3-3 |
| 3.4 | Alternator Assembly | 3-5 |
| 3.5 | Engine Pulley Guards | 3-7 |
| SECTION 4 | ELECTRICAL INFORMATION | 4-1 |
| 4.1 | Electrical Symbol Diagram, G25 LT40 Series | 4-1 |
| 4.2 | Electrical Symbol Diagram, LT40 Series | 4-2 |
| 4.3 | Electrical Components, G25 LT40 non-hydraulic | 4-3 |
| 4.4 | Electrical Components, G25 LT40 hydraulic | 4-4 |


ABOUT THIS MANUAL

This manual is provided as a supplement to the equipment manufacturer's manuals. This manual provides information specific to the use of this equipment on the Wood-Mizer® sawmill. Refer to the sawmill operator's manual and manufacturer's manual before attempting to operate this equipment.



IMPORTANT! Read the sawmill operator's manual and engine manufacturer's manual for instructions and safety precautions before operating this equipment.

The information and instructions given in this manual do not amend or extend the limited warranties for the equipment given at the time of purchase.



ENGINE COMPONENTS

SECTION 1 OPERATION

1.1 Starting The Engine

Engine Control Lights

See **Figure 1-1**. The following indicator lights are located on the sawmill control panel.



Alternator Charge Indicator: Lights up if the alternator is not charging the battery.



Engine Temperature Indicator: Lights up if the engine is overheating. A circuit breaker assembly in the engine harness will shut the engine off if the engine overheats. Turn the key switch off and allow the engine to cool for a period of time before restarting. If the overheating condition persists, stop operating the engine until the condition is corrected. The engine will automatically switch to low idle if an overheating condition occurs.



Oil Indicator: Lights up if the oil pressure is too low.




FIG. 1-1

Engine Start



DANGER! Always be sure the blade is disengaged and all persons are out of the path of the blade before starting the engine. Failure to do so will result in serious injury.

DANGER! Operate your engine/machine only in well ventilated areas. The exhaust gases of your engine can cause nausea, delirium and potentially death unless adequate ventilation is present.

DANGER! Never operate an engine with a fuel or oil leak. The leaking fuel or oil could potentially come in contact with hot surfaces and ignite into flames.



WARNING! Be sure the power feed switch is in the neutral position before turning the key switch to the on (#1) or accessory (#3) position. This prevents accidental carriage movement, which may cause serious injury or death.

WARNING! Do not operate engine without proper and operational spark arrester/muffler. Sparks emitted from the engine exhaust could ignite surrounding materials, causing serious injury or death.

Turn the key switch to the start (#2) position and release.



Operation

Starting The Engine

Engine Shutoff

Turn the key switch to the off (#0) position.

SECTION 2 MAINTENANCE

Refer to the manufacturer's manual for maintenance intervals and procedures unless otherwise instructed in this manual. Follow the manufacturer's recommendations for dusty conditions.



IMPORTANT! This manual only provides information about additional procedures or procedures to be performed at different time intervals than found in the manufacturer's manuals. Refer to the manufacturer's manual for complete maintenance instructions.

2.1 Safety

Use caution when performing maintenance or service to the engine.



DANGER! Always be aware of and take proper protective measures against rotating shafts, pulleys, fans, etc. Always stay a safe distance from rotating members and make sure that loose clothing or long hair does not engage rotating members resulting in possible injury.

DANGER! Engine components can become very hot during operation. Avoid contact with any part of a hot engine. The exhaust components of your engine are especially hot during and following operation. Contact with hot engine components can cause serious burns. Therefore, never touch or perform service functions on a hot engine. Allow the engine to cool sufficiently before beginning any service function.



WARNING! Remove the blade before performing any engine service. Failure to do so may result in serious injury.

WARNING! Always wear proper and necessary safety equipment when performing service functions. Proper safety equipment includes eye protection, breathing protection, hand protection and foot protection.



This symbol identifies the interval (hours of operation) at which each maintenance procedure should be performed. "AR" signifies maintenance procedures which should be performed as required.

2.2 Engine Oil & Filter



Check the oil level every 8 hours of operation. Add oil as necessary. See the engine manual for oil viscosity and grade recommendations.



IMPORTANT! During initial break-in, change the oil and the oil filter after the first 5 hours and every 50 hours thereafter. Continue to check oil level every 8 hours of operation and refill as necessary.



NOTE: Engine in factory is filled with 10W/40 Shell Helix HX7, semi-synthetic oil.

2.3 Cooling System



Wash the engine or brush off sawdust and debris every 50 hours of operation. Clean the grass screen, cooling fins, and external surfaces. Remove any dust, dirt or oil. See engine manual for further instructions.

2.4 Air Filter & Pre-Cleaner



WARNING! Always wear proper and necessary safety equipment when performing service functions. Proper safety equipment includes eye protection, breathing protection, hand protection and foot protection.



Service the pre-cleaner every four hours of operation. Service by gently shaking excess sawdust and debris from the foam piece.



Clean the air filter (air cleaner element) and pre-cleaner (element wrapper) every eight hours of operation. See the engine manual for further instructions.



Replace the air filter (cleaner) every 200 hours of operation.



Replace the pre-cleaner (element wrapper) every 2000 hours of operation.

2.5 Fuel Filter



Replace the fuel filter every 100 hours of operation.

2.6 Battery



Check the battery electrolyte level every 50 hours of operation. See manufacturer's manual for instructions.



DANGER! Batteries expel explosive gases. Keep sparks, flames, burning cigarettes, or other ignition sources away at all times. Always wear safety goggles and a face shield when working near batteries. Failure to do so will cause serious injury.¹



WARNING! Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. Wash hands after handling.

1. Battery Council International, copyright 1987

2.7 Alternator Belt



Adjust the alternator belt as needed. Check the alternator belt for tension and wear when battery is not charging properly or when the alternator belt is squealing. To tighten the belt, loosen the adjustment bolt and lock washer. Pivot the alternator away from the motor until the belt has 7/16" (11 mm) deflection with a 5 lb. deflection force. Retighten the adjustment bolt.

See Figure 2-1.




FIG. 2-1

2.8 RPM Adjustments



WARNING! Remove the blade before performing any engine service. Failure to do so may result in serious injury.



Check the RPM with a tachometer after the first 20 hours of operation and every 200 hours thereafter. High-end RPM should be 3750 RPM and low-end RPM should be 1800 RPM (± 100).

Before checking the RPM, make sure belt and brake strap tensions are correct (See Sawmill Maintenance). Also check oil, fuel, and coolant levels.

Make sure the throttle cable does not affect the engine RPM when the clutch handle is disengaged. Make sure the cable is not bent or kinked. Check that the cable spring, cable guide, cable, and throttle brackets are aligned. **NOTE:** It is important that the above components are aligned. Proper alignment allows any slack in the cable (when engine is idling) to slide down into the cable spring. This maintains free operation of the cable and prevents the cable from kinking. Make sure the shoulder bolt does not rub against the crankcase vent tube.

1. Start the engine to measure the low-end RPM.
2. Refer to the engine manual to adjust the low-end RPM.
3. Engage the clutch handle to throttle the engine and measure the high-end RPM. The high-end RPM is factory-set at 3750. Readjust the throttle cable if necessary to increase or reduce the high-end engine speed.

The throttle cable should be tensioned just enough so that the engine revs as soon as the clutch/brake handle is engaged. **NOTE:** A properly adjusted throttle will extend the cable spring 1/4" to 3/8" (6.4 - 9.5 mm) when running and have a slight amount of slack in the cable when idling.

2.9 Drive Belt Adjustment



WARNING! Do not for any reason adjust the engine drive belts or belt support bracket with the engine running. Doing so may result in serious injury.


50

Check the drive belt tension after the first 20 hours, and every 50 hours thereafter. When engaged, the drive belt should have 7/16" (11 mm) deflection with a 15 lb. deflection force (67 N).

To adjust drive belt tension:

1. Loosen the drive belt turnbuckle jam nuts. Turn the turnbuckle counterclockwise (as viewed from the top) to tighten the belts, clockwise to loosen the belts.

Patrz rysunek 2-2.



RYS. 2-2


AR

Periodically check all belts for wear. Replace any damaged or worn belts as needed.

2.10 Clutch Handle Adjustment

After the drive belts and brake strap are properly adjusted, the clutch handle should lock in the down position when the drive belts are engaged. If the clutch handle does not stay locked, adjust the handle turnbuckle.

Patrz rysunek 2-3.



RYS. 2-3

#1 - Brake locked, belt loosened

#2 - Intermediate position (blade replacement): brake unlocked, drive not engaged

#3 - Belt tightened, drive engaged

2.11 Miscellaneous Maintenance



Clean and inspect the spark arresters every 50 hours of operation. Replace if damaged.




Inspect the spark plugs every 100 hours of operation. Remove any deposits and adjust gap if necessary. See engine manual for further information.



CAUTION! Do not remove the plug wire to check for electrical spark. Damage to the ignition circuit will result.

SECTION 3 REPLACEMENT PARTS

3.1 Fuel Tank Assembly




| REF | DESCRIPTION (◆ Indicates Parts Available In Assemblies Only) | PART # | QTY. | |
|-----|--|---------------------|------|---|
| | TANK ASSEMBLY, 5-GALLON RED GASOLINE | A12285 | 1 | |
| 1 | Tank, 5-Gallon Red Fuel | P12167 | 1 | ◆ |
| 2 | Pickup, 9" Fuel | P12172 | 1 | |
| 3 | Cap, 3 or 5-Gallon Fuel Tank | P09683 | 1 | |
| 4 | Fitting, 1/4" NPT Plastic Female Disconnect | P12175 | 1 | |
| | HOSE, FUEL LINE WITH PRIMER BULB | 014497 | 1 | |
| | Bulb Kit, Fuel Primer Replacement | 014496 | 1 | |
| 5 | Bulb, Fuel Primer | 014481 | 1 | ◆ |
| 6 | Clamp, 1/2" OD Plastic Hose | P12374 | 2 | |
| | Instruction Sheet, Fuel Primer Bulb Replacement | 014496-590 | 1 | |
| 7 | Hose, 1/4" ID Fuel | R01890-1 | 2 m | |
| 8 | Clamp, 1/2" OD Plastic Hose | P12374 | 1 | |
| 9 | FITTING, 1/4" NPT PLASTIC MALE DISCONNECT | P12176 ¹ | 1 | |

¹ Replacement requires qty. 1 hose clamp (P12374).

3 Replacement Parts


Engine Mount Assembly

3.2 Engine Mount Assembly



| REF | DESCRIPTION (◆ Indicates Parts Available In Assemblies Only) | PART # | QTY. | |
|-----|--|-----------|------|---|
| 1 | MOUNT WELDMENT, KOHLER ENGINE | 086803-1 | 1 | ◆ |
| | BUSHING ASSEMBLY, MOTOR MOUNT | 016380 | 3 | |
| 2 | Bushing, 2" OD x 2" | 016378 | 1 | ◆ |
| 3 | Bearing, 1" x 1 1/4" x 2" | 016379 | 1 | ◆ |
| 4 | CLAMP WELDMENT , MOTOR MOUNT PIVOT BUSHING | 086235 | 3 | |
| 5 | BOLT, M10-1.5X25MM HH GR8.8 | F81003-11 | 3 | |
| | BOLT, M10X45MM,HEX HEAD,FULL THRD,ZINC | F81003-31 | 3 | |
| 6 | NUT, M10, NYLON HEX ZINC LOCK | F81033-11 | 6 | |
| 7 | BOLT M12X30-8.8 | F81004-22 | 1 | |
| 8 | PIN WELDMENT, ENGINE MOUNT PIVOT | 099130-1 | 1 | |
| 9 | NUT, M12, HEXAGON, NYLON, ZINC, LOCK | F81034-2 | 1 | |
| 10 | WASHER, M12 , FLAT, ZINC | F81056-1 | 1 | |

3.3 G25 Engine Assembly



| REF | DESCRIPTION (◆ Indicates Parts Available In Assemblies Only) | PART # | QTY. | |
|-----|--|----------|------|---|
| | ENGINE ASSEMBLY, 25HP KOHLER | 015955 | 1 | |
| 1 | Engine, 25Hp Kohler CH25 | P12529 | 1 | ◆ |
| 2 | Filter, Kohler Air #24-083-03-S | 092347 | 1 | ◆ |
| 3 | Pre Cleaner, Kohler #24-083-05-S | 092348 | 1 | ◆ |
| | Plug, RC12YC Kohler Spark #12-132-02-S | P12757 | 2 | |
| 4 | Filter, Kohler Oil #52-050-02-S | 092349 | 1 | |
| 5 | Filter, Kohler Fuel #25-050-02-S | 092350 | 1 | |
| 6 | Muffler, Kohler #24-786-12-S | 092351 | 1 | ◆ |
| 7 | Guard, Muffler, Kohler | 091859-1 | 1 | |
| 8 | Cable, 18" Throttle | P12313 | 1 | |
| | Spring, Throttle | 016033 | 1 | |


3

Replacement Parts

G25 Engine Assembly

| | | | | |
|----|--|-----------|--------|---|
| 9 | Bracket, Throttle Cable Mount | 091567-1 | 1 | |
| 10 | Spring, .5" x .08" x 1 3/8" Extension | 015952 | 1 | |
| 11 | Bracket, G25 Throttle | 091565-1 | 1 | |
| 12 | Bolt, M5x16, HH, GR 8.8, Zinc | F81000-20 | 1 | |
| 13 | Nut, M5-8, HEX, NYLON LOCK ZINC | F81030-2 | 1 | |
| 14 | Hose, 7" Oil Drain | P10082 | 1 | |
| 15 | Cap, Oil Drain 3/8" Pipe | P04332 | 1 | |
| | Oil, 10W30 Type CD | L04869-1 | .5 Gal | ◆ |
| 16 | Pulley, Zinc | 091566-1 | 1 | |
| 17 | Bushing, Split Taper | 091572 | 1 | |
| 18 | Key, 1/4" x 1/4" x 1 11/16" | S04124 | 1 | |
| 19 | Decal, Kohler Spark Caution | 016027 | 2 | |
| 20 | Bracket Weldment, Drive Belt Support Painted | 091582-1 | 2 | ◆ |
| 21 | WASHER, FLAT, M10, ZINC | F81055-1 | 10 | |
| 22 | WASHER, M10 SPLIT LOCK ZINC | F81055-2 | 2 | |
| 23 | BOLT, 3/8-16X3/4 HH GR2 | F05007-27 | 2 | |
| 24 | BOLT, M10X30MM, HEX HEAD, GR 5.8 ZINC | F81003-20 | 4 | |
| 25 | NUT, M10, NYLON HEX ZINC LOCK | F81033-1 | 4 | |
| 26 | BELT, 2BX72 DRIVE | P09555-2 | 1 | |
| 27 | BAR, GP25 ENGINE MOUNT PTD | 091564-1 | 2 | |

3.4 Alternator Assembly




| REF | DESCRIPTION (◆ Indicates Parts Available In Assemblies Only) | PART # | QTY. |
|-----|--|-----------|------|
| 1 | ALTERNATOR, 12V 105A | 050287 | 1 |
| 2 | BRACE, ALTERNATOR | W12761 | 1 |
| 3 | WASHER, FLAT, M10, ZINC | F81055-1 | 1 |
| 4 | BOLT, 3/8-16 X 5 1/2" HEX HEAD FULL THREAD | F05007-34 | 1 |
| 5 | NUT, 3/8-16 HEX NYLON LOCK | F05010-10 | 1 |
| 6 | WASHER, M8, FLAT, ZINC | F81054-1 | 1 |
| 7 | WASHER, 8,2 SPLIT LOCK ZINC | F81054-4 | 1 |
| 8 | BOLT, M8 X 25MM HEX HEAD GR 5.8 ZINC | F81002-5 | 1 |
| 9 | WASHER, M8, FLAT, ZINC | F81054-1 | 1 |
| 10 | WASHER, 8,2 SPLIT LOCK ZINC | F81054-4 | 1 |
| 11 | BOLT, M8 X 25MM HEX HEAD GR 5.8 ZINC | F81002-5 | 1 |
| 12 | PULLEY, ALTERNATOR | P03806 | 1 |
| 13 | BELT, ALTERNATOR E15 13X920 "A" | 085753 | 1 |
| | WIRE ASSEMBLY, G25 ALTERNATOR/STARTER | 024308 | 1 |
| | WIRE ASSEMBLY, 61/105 AMP ALTERNATOR PLUG | 015969 | 1 |
| 14 | BRACKET, ALTERNATOR MOUNT | 092015-1 | 1 |

3**Replacement Parts***Alternator Assembly*

| | | | | |
|----|--------------------------------------|-----------|---|--|
| 15 | WASHER, FLAT, M10, ZINC | F81055-1 | 2 | |
| 16 | WASHER, M10 SPLIT LOCK ZINC | F81055-2 | 3 | |
| 17 | BOLT, M10X20MM,HEX HEAD,GR 5.8 ZINC | F81003-1 | 2 | |
| 18 | GUARD, ALTERNATOR BELT | 091583-1 | 1 | |
| 19 | BOLT, M6X20MM, HH, FULL THREAD, ZINC | F81001-2 | 1 | |
| 20 | BOLT, M6X12MM HEX HEAD ZINC | F81001-7 | 2 | |
| 21 | WASHER, M6, FLAT, ZINC | F81053-11 | 3 | |


3.5 Engine Pulley Guards



| REF | DESCRIPTION (◆ Indicates Parts Available In Assemblies Only) | PART # | QTY. |
|-----|--|-----------|------|
| 1 | GUARD WELDMENT, G18/G20/G25 ENGINE PULLEY | 091571-1 | 1 |
| 2 | GUARD, G18/G20/G25 SIDE ENGINE PULLEY | 087178-1 | 1 |
| 3 | BOLT, M6X12MM HEX HEAD ZINC | F81001-7 | 4 |
| 4 | WASHER, M6, FLAT, ZINC | F81053-11 | 4 |
| 5 | GROMMET, 1" ID RUBBER | P11765 | 1 |

SECTION 4 ELECTRICAL INFORMATION

4.1 Electrical Symbol Diagram, G25 LT40 Series



RYS. 4-1

4.2 Electrical Symbol Diagram, LT40 Series



RYS. 4-2

4.3 Electrical Components, G25 LT40 non-hydraulic

| Item | Mfg. Part No. | Manufacturer | WM Part # | Description |
|------|---------------|--------------|-----------|---|
| A1 | CS-130 | Delco-Remy | 050287 | Alternator, 12 Volt, 105 A |
| B1 | #95601 | BANNER | 088322 | Battery, 12 V |
| CB1 | 30128-30 | Cole-Hersee | E20486 | Circuit Breaker, 30 Amp, 12 Volt, For Power Feed Motor, Auto Reset |
| F1 | RL-150 | Gould | 023361 | Fuse Link, 150 Amp, 250 Volt For Main + 12 Volt Starter, Alternator |
| H1 | T14BH517BC9 | ENM Corp. | 015401 | Hour Meter, 12 Volt, Low Power T14 Series |
| KS1 | 121801 | General | P04350 | Key Switch, 4-position (Accessory, Off, Ignition, Start) |
| M1 | PR4R0009Q | Owosso | 014359 | Motor, 12 Volt Power Feed |
| M2 | PR-4P07Q | Owosso | A07974 | Motor, 12 Volt Up/Down |
| M3 | P09698-1 | Klauber | A10365 | Motor, 12 Volt Blade Guide Arm 53:1 Gear |
| PCB1 | 015410 | Wood-Mizer | 015410 | Circuit Board, Control Box |
| PCB2 | 015416 | Wood-Mizer | 015416 | Circuit Board, LED Circuit (Gas/Elec) |
| S1 | 2601-AF2-S11 | Square D | E20439 | Drum Switch, (U.S.), Power Feed Fwd/Reverse Motor |
| S2 | 2601-AF2-S12 | Square D | E20440 | Drum Switch, Up/Down Motor |
| S3 | 34-591Q | Pollak | 024200 | Toggle Switch, Blade Guide In/Out Motor |
| PK1 | - | - | 092284 | Relay, Safety Key Switches |
| P1 | XB4BS542 | Schneider | 086556 | Switch, Emergency Stop |

TABELA 4-1

4.4 Electrical Components, G25 LT40 hydraulic

| Item | Mfg. Part No. | Manufacturer | WM Part # | Description |
|------|---------------|--------------|-----------|---|
| A1 | CS-130 | Delco-Remy | 050287 | Alternator, 12 Volt, 105 A |
| B1 | #95601 | BANNER | 088322 | Battery, 12 V |
| CB1 | 30128-30 | Cole-Hersee | E20486 | Circuit Breaker, 30 Amp, 12 Volt, For Power Feed Motor, Auto Reset |
| F1 | RL-150 | Gould | 023361 | Fuse Link, 150 Amp, 250 Volt For Main + 12 Volt Starter, Alternator |
| F2 | RL-225 | Gould | P11550 | Fuse Link, 225 Amp, 250 Volt For Hydraulic +12 Volt Circuit |
| H1 | T14BH517BC9 | ENM Corp. | 015401 | Hour Meter, 12 Volt, Low Power T14 Series |
| KS1 | 121801 | General | P04350 | Key Switch, 4-position (Accessory, Off, Ignition, Start) |
| M1 | PR4R0009Q | Owosso | 014359 | Motor, 12 Volt Power Feed |
| M2 | PR-4P07Q | Owosso | A07974 | Motor, 12 Volt Up/Down |
| M3 | P09698-1 | Klauber | A10365 | Motor, 12 Volt Blade Guide Arm 53:1 Gear |
| M4 | 8111 | Monarch Hyd. | P09955 | Motor, 12 Volt Hydraulic Pump |
| PCB1 | 015410 | Wood-Mizer | 015410 | Circuit Board, Control Box Power Feed |
| PCB2 | 015416 | Wood-Mizer | 015416 | Circuit Board, LED Circuit (Gas/Elec) |
| S1 | 2601-AF2-S11 | Square D | E20439 | Drum Switch, (U.S.), Power Feed Fwd/Reverse Motor |
| S2 | 2601-AF2-S12 | Square D | E20440 | Drum Switch, Up/Down Motor |
| S3 | 34-591Q | Pollak | 024200 | Toggle Switch, Blade Guide In/Out Motor |
| S4 | 024198 | Wood-Mizer | 024198 | Switch, Hydraulic Pump Levers |
| SOL1 | 586-902 | Stancor | 015470 | Solenoid, 200A 12V SPST Hydraulic Pump Motor |
| PK1 | - | - | 092284 | Relay, Safety Key Switches |
| P1 | XB4BS542 | Schneider | 086556 | Switch, Emergency Stop |

TABELA 4-2