

EA20 Motor

Safety, Operation, Maintenance & Parts Manual

LT30A Super	rev. B5.00
LT40A Super	rev. B5.00
LT30AHD Super	rev. B5.00
LT40AHD Super	rev. B5.00



Safety is our #1 concern! Read and understand all safety information and instructions before operating, setting up or maintaining this machine.

November 1998

Form #971

	Section-Page
SECTION 1 SAFETY & GENERAL INFORMATION	1-1
1.1 Motor Operation	1-1
1.2 Electrical Operation.....	1-2
SECTION 2 OPERATION	2-1
2.1 Starting The Motor	2-1
SECTION 3 MAINTENANCE	3-1
3.1 Drive Belt Adjustment.....	3-1
SECTION 4 REPLACEMENT PARTS	4-1
4.1 How To Use The Parts List	4-1
4.2 Sample Assembly	4-1
4.3 Motor Starter Assembly	4-2
4.4 Motor Assembly	4-3
4.5 Motor Pulley Guards, EA20.....	4-4
SECTION 5 ELECTRICAL INFORMATION	5-1
5.1 Electrical Symbol Diagram, EA20.....	5-1
5.2 Main Electrical Box Diagram.....	5-4
5.3 Main Electrical Box Components	5-5
5.4 HD Electrical Box Diagram (HD Sawmills Only)	5-6
5.5 HD Electrical Box Components (HD Sawmills Only).....	5-6
SECTION 6 BRAKE AIR GAP ADJUSTMENT	6-1

SECTION 1 SAFETY & GENERAL INFORMATION



IMPORTANT! This manual is provided as a supplement to the equipment manufacturer's manuals. This manual takes into account the specific use of engines on the Wood-Mizer sawmill. Only safety, maintenance, and operating procedures that are not provided by the manufacturer are supplied in this manual. Refer to the manufacturer's manual before attempting to operate this equipment.



This symbol calls your attention to instructions concerning your personal safety. Be sure to observe and follow these instructions. This symbol accompanies a signal word. The word **DANGER** indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury. **WARNING** suggests a potentially hazardous situation which, if not avoided, could result in death or serious injury. **CAUTION** refers to potentially hazardous situations which, if not avoided, may result in minor or moderate injury to persons or equipment. Read all safety instructions before operating this equipment and observe all safety warnings!

1.1 Motor Operation



DANGER! Always be sure the blade is disengaged and all persons are out of the path of the blade before starting the engine or motor. Failure to do so will result in serious injury.



WARNING! Do not for any reason adjust the motor drive belts or belt support bracket with the motor running. Doing so may result in serious injury.

WARNING! Remove the blade before performing any motor service. Failure to do so may result in serious injury.



WARNING! Be sure the power feed switch is in the neutral position before turning the key switch to the (#1) or (#2) position. This prevents accidental carriage movement, which may cause serious injury or death.

1.2 Electrical Operation



DANGER! Make sure all electrical installation, service and/or maintenance work is performed by a qualified electrician and is in accordance with applicable electrical codes.

DANGER! Hazardous voltage inside the disconnect box, starter box, and at the electric motor can cause shock, burns, or death. Disconnect and lock out power supply before servicing! Keep all electrical component covers closed and securely fastened during mill operation.


SECTION 2 OPERATION

2.1 Starting The Motor

Engine Control Lights

See Figure 2-1. The following indicator lights are located on the sawmill control panel.

 **Key Switch Indicator:** Lights up when the key is in either the (#1) or (#2) position.



AC0022

FIG. 2-1

Motor Start



DANGER! Always be sure the blade is disengaged and all persons are out of the path of the blade before starting the engine or motor. Failure to do so will result in serious injury.



WARNING! Be sure the power feed switch is in the neutral position before turning the key switch to the (#1) or (#2) position. This prevents accidental carriage movement which may cause serious injury or death.

Turn the key switch to the start (#2) position and press the “START” button on the control panel.

Motor Shutoff

Turn the key switch to the off (#0) position and press the “STOP” button on the control panel.

SECTION 3 MAINTENANCE



This symbol identifies the interval (hours of operation) which each maintenance procedure should be performed. "AR" signifies maintenance procedures which should be performed as required.

3.1 Drive Belt Adjustment



Periodically check all belts for wear. Replace any damaged or worn belts as needed.



DANGER! Do not for any reason adjust the drive belt support with the motor running. Always stop the motor before reaching or looking into the drive belt area.

SECTION 4 REPLACEMENT PARTS

4.1 How To Use The Parts List

- Use the table of contents or the index to locate the assembly that contains the part you need.
- Go to the appropriate section and locate the part in the illustration.
- Use the number pointing to the part to locate the correct part number and description in the table.
- Parts shown indented under another part are included with that part.
- Parts marked with a diamond (◆) are only available in the assembly listed above the part.

See the sample table below. Sample Part #A01111 includes part F02222-2 and subassembly A03333. Subassembly A03333 includes part S04444-4 and subassembly K05555. The diamond (◆) indicates that S04444-4 is not available except in subassembly A03333. Subassembly K05555 includes parts M06666 and F07777-77. The diamond (◆) indicates M06666 is not available except in subassembly K05555.


4.2 Sample Assembly

REF	DESCRIPTION (◆ Indicates Parts Available In Assemblies Only)	PART #	QTY.	
SAMPLE ASSEMBLY, COMPLETE (INCLUDES ALL INDENTED PARTS BELOW)				
1	Sample Part	F02222-22	1	
	Sample Subassembly (Includes All Indented Parts Below)	A03333	1	
2	Sample Part (◆ Indicates Part Is Only Available With A03333)	S04444-4	1	◆
	Sample Subassembly (Includes All Indented Parts Below)	K05555	1	
3	Sample Part (◆ Indicates Part Is Only Available With K05555)	M06666	2	◆
4	Sample Part	F07777-77	1	

To Order Parts:


- From Europe call our European Headquarters and Manufacturing Facility in Kolo, Poland at **+48-63-2610233** or **+48-3912-1319**. From the continental U.S., call **1-800-448-7881** to order parts. Have your customer number, vehicle identification number, and part numbers ready when you call.
- From other international locations, contact the Wood-Mizer distributor in your area for parts.

4.3 Motor Starter Assembly



REF	DESCRIPTION (◆ Indicates Parts Available In Assemblies Only)	PART #	QTY.
	STARTER ASSEMBLY, 20HP SUPER ELECTRIC MOTOR	086564	1
1	Box, AC Super Electric Motor Starter	087668	1
2	Connector, GP29 Click 6180 0910	086576	3
3	Bolt, M8 x 30-8.8-B Hex Head	F81002-7	4
4	Nut, M8-8-B Hex	F81032-1	4
	Controller, ALTIVAR Electric Motor Speed	086549	1
	Cord, 61746970 Rill 21	086557	1.15 m
	Cord, 61746980 Rill 29	086558	1.15 m
	Nut, 53019050 GMP-GL 21	086559	1
	Nut, 53019060 GMP-GL 29	086560	1
	Ring, 021 Sealing 5200 5750	086578	1
	Ring, 029 Sealing 5300 1040	086579	1
	Sleeve, Connector NW 6,3/1	F81079-4	4


4.4 Motor Assembly



3H0001P

REF	DESCRIPTION (♦ Indicates Parts Available In Assemblies Only)	PART #	QTY.	
	MOTOR ASSEMBLY, AC 20HP (15KW) ELECTRIC	EA20	1	
1	MOTOR, 20HP (15KW) ELECTRIC EURO HPS	087396	1	
	MOUNT WELDMENT, E20/E25 ELECTRIC MOTOR	086801-1	1	
	PULLEY, EA20/EA25 ELECTRIC MOTOR	085671	1	
	BELT, 3BX74 DRIVE	014249	1	

4.5 Motor Pulley Guards, EA20.



REF	DESCRIPTION (♦ Indicates Parts Available In Assemblies Only)	PART #	QTY.
1	GUARD WELDMENT, EA20/EA25 MOTOR PULLEY	087059-1	1
2	SUPPORT, DRIVE BELT UPPER	085865-1	1
3	SUPPORT, DRIVE BELT LOWER	085922-1	1

SECTION 5 ELECTRICAL INFORMATION

5.1 Electrical Symbol Diagram, EA20





FIG. 5-1 SYMBOL DIAGRAM.

Description (See Figure 5-1):

G1-	Socket 32A 380V
Q -	Main Switch
1M -	Soft Start Switch Contactor
F1M -	Blade Motor Safety Switch
2S -	Inverter Contactor
3S, 4S -	Up/Down Switch Contactor
FS3/4 -	Up/Down Motor Thermal Relay
6S -	Up/Down Motor Speed Control Contactor
5S -	Debarker Contactor
FS5 -	Thermal Debarker Relay
F1 -	Autoswitch S193
M1-	Blade Motor
M2 -	Power Feed Motor
M3 -	Up/Down Motor
M4 -	Debarker Motor (Optional)
M5 -	Blade Cover Motor
M6 -	Board Return Motor
M7 -	Debarker Arm Motor
L1 -	White Lamp (Power On)
L2 -	Green Lamp (Ready To Operate)
L3 -	Lamp on the Control Box (Power On)
L4 -	Lamp on the Control Box (Ready To Operate)
Pr -	Bridge-Rectifire
W1 -	Loading Position Limit Switch
W2, W3 -	Blade Cover Limit Switch
P12 -	Debarker Relay
P24 -	Limit Switch Relay
SS -	Motor Starter
F2, F3, F4 -	Autoswitch S193
Tr1 -	Transformer
WŠ1 -	Debarker Switch
WŠ2 -	Speed Control Switch
Pr1-	Blade Cover Motor Switch
Pr2 -	Board Return Switch
Pr3 -	Debarker Arm Motor Switch
G/D -	Up/Down Switch
P/T -	Power Feed Switch
ALTIVAR -	Up/Down Motor Speed Controller
H -	Electric Motor Brake
PrH -	Electric Motor Bridge-Rectifire (inside the motor)

5.2 Main Electrical Box Diagram

**FIG. 5-2**

5.3 Main Electrical Box Components

ID	Mfg. Part No.	Manufacturer	Wood-Mizer Part #	Description
F1	C60N C10 24349	SCHNEIDER	084317	Switch
Q	40A KU 340	KATKO	084331	Switch
F2, F3	-	-	084316	Circuit Breaker 15A
T1	TMA160SL 240/280/415/24/14V	EFA	084315	Transformer
TDR	LA2DS2	SCHNEIDER	084037	Time Relay
F1M	LR2D1322	SCHNEIDER	084304	Thermal Relay
F5S, F3/4S	LR2KO308	SCHNEIDER	084312	Thermal Relay
ALTIVAR	ATV-18U29N4	SCHNEIDER	086549	Motor Speed Controller
P12	12V DC 40.52	FINDER	084314	Relay
P24	24V AC 40.51	FINDER	084313	Relay
Pp	24V AC 40.51	FINDER	084313	Relay
1M	LC1 D11810 B7	SCHNEIDER	084307	Contactor
2M	LC1 D1801 B7	SCHNEIDER	084306	Contactor
1S	LC1 D0901 B7	SCHNEIDER	084305	Contactor
3S, 4S	LC1 K0601 B7	SCHNEIDER	084309	Contactor
2S, 5S, 6S	LC1 K0610 B7	SCHNEIDER	084308	Contactor
PR	KBPC 3508	-	084318	Bridge-Rectifier
L1	FT22/220V AC	-	084310	White Lamp (Power On)
L2	FT22/24V AC	-	084311	Green Lamp (Ready to Operate)

TABLE 5-1

5.4 HD Electrical Box Diagram (HD Sawmills Only)




FIG. 5-3


5.5 HD Electrical Box Components (HD Sawmills Only)

ID	Mfg. Part No.	Manufacturer	Wood-Mizer Part #	Description
Q	25A KU325	KATKO	084450	Switch
1M	LC1 K0910 B7	SCHNEIDER	084451	Contactor
CKF	RM3 TG201 MS7	SCHNEIDER	084452	Phase Control Sensor
PC	RE6 RA 11MW	SCHNEIDER	084453	Time Relay
F1, F2	C60N 24395	SCHNEIDER	084454	Switch
F1M	LR2K0314	SCHNEIDER	084455	Thermal Relay
F1M	LR2K0316	SCHNEIDER	084456	Thermal Relay

TABLE 5-2

SECTION 6 BRAKE AIR GAP ADJUSTMENT

To ensure proper operation of the brake, it is necessary to set correctly the air gap between the armature and the electromagnet. Each time the brake is installed or the brake sub-assemblies are replaced or the motor overheats or the brake is inspected (**the inspection should be performed at least every six months**), check and, if necessary, adjust the brake air gap.



- 1 - body,
- 5 - armature,
- 6 - mounting bolt,
- 7 - brake casing,
- 8 - adjustment bolt,
- 9 - mounting disk,
- 15 - bearing shield.

Adjustment of the brake air gap is performed when the gap has reached the maximum value (see Table 1), and always after dismounting the brake and replacing or performing maintenance of damaged subassemblies.

Table 1

Parameter	HPS 06	HPS 08	HPS 10	HPS 12	HPS 14	HPS 16	HPS 18	HPS 20	HPS 25
“a” nom.	0,20	0,20	0,20	0,30	0,30	0,30	0,30	0,30	0,40
“a” max.	0,50	0,50	0,50	0,70	0,80	1,00	1,20	1,20	1,40

To adjust the air gap, perform the following steps :

- Dismount the motor casing,
- Remove the brake casing (7),
- Loosen the mounting bolts (6) half a turn using an adequate allen wrench (see wrench sizes in Table 2),

Table 2

	HPS 06	HPS 08	HPS 10	HPS 12	HPS 14	HPS 16	HPS 18	HPS 20	HPS 25
Wrench size (mm)	3	4	5	5	6	6	6	8	8

- Screw the adjustment bolts (8) in the electromagnet body one turn using an adequate flat wrench (see wrench sizes in Table 3),

Table 3

	HPS 06	HPS 08	HPS 10	HPS 12	HPS 14	HPS 16	HPS 18	HPS 20	HPS 25
Wrench size (mm)	10	10	12	12	14	14	14	17	17

- Place the gap gauge (17) in the gap between the armature (5) and the electromagnet body (1). The thickness of the gauge should equal the nominal brake gap (see Table 1),
- Using the mounting bolts (6), press the body (1) to the armature so that the gap gauge can be removed at slight resistance and at the same resistance insert the gap gauge into gaps located every 120° from the place of the first measurement,
- Unscrew the adjustment bolts (8) so that they rest on the motor bearing shield or on the face of the brake mounting disk (9) (in brakes equipped with this element),
- Tighten the brake mounting bolts (6) and check the gap for correct adjustment with the gap gauge.